

Full Arch & Full Zirconia

1st step) Initial Impression:

- Dr. takes initial impression with **Pick-up Impression Coping (Open Tray)**.
*** Use **MUA** if applicable (Make sure no metal is showing facially)
- Dr. may use Transfer Impression Coping (for closed tray)
→ [Send Pick-up Impression Copings separately](#) for lab to make [Verification Jig](#) **[MUST]**

2nd step) Verification Jig & Custom Tray [1 week] → 2nd impression:

- Lab sends Sectioned verification jig (We will number 1, 2, 3, 4) & Custom Tray
- In the patient's mouth, place the sectioned jig in order (1, 2, 3, 4...) and lute them together with [Pattern Resin](#) intraorally.
- **Take X-Ray (MUST)** to make sure there is **no gap** between implant and impression coping
- Take pick-up impression over luted Jig.
- [send Impression, 2 Non-Hex Temporary Abutments \(for Wax Rim\)](#) & X-Ray to lab

3rd Step) Screw-Retained Implant Wax Rim [1 week] → Bite & VDO, Making Midline & Occlusal Plane on Wax Rim by using Q-Tip w/ Bluemoose:

Lab sends Screw-retained Wax Rim (using 2 Temporary Abutments) for Bite & VDO

4th Step) Teeth Try In [1 week]

5th Step) Bisque Try In [2-3 weeks]

6th Step) Finish [1 week]